

Brine Valve Housing Assembly

1	93620	Piston Assembly 1	
		(includes O-ring Spring	
2	90821	O-Ring 1	
3	93260	Housing 1	
4	93878	Quad Ring 1	
5	93254	Quad Ring Retainer 1	
6	90843	.5 pm Flow Control 1	
7	93805	O-Ring 1	
8	54315	Housing Cap Assembly 1	
9	90807	Screw 2	
10	54315	Elbow 1	
11	90828	O-Ring (not shown) 1	

