

Injector Assembly

1	93223	Injector Throat	1
2	93220	Bottom (Thick) Injector Seal	1
3	93220	Injector Nozzle	1
4	93232	Bottom (Thin) Injector Seal	1
5	93222	Injector Cap	4
6	93807	Injector Screw	1
7	93810	Injector Screen	1
	93501	Injector Assembly (includes all above items)	1

